

NIMBUS 3963/3964 RFID Digital Combination Lock

* PRESS AND HOLD LOGO BUTTON FOR 2 SECONDS

FUNCTION	MODE						KEY SEQUENCE	NOTES
	Public	Private		RAS		RAS Code		
	4 digit (Single User)	6 digit (Single User)	4 digit (Single User)	4 digit (Multi User)	6 digit (Single User)	6 digit (Single User)		
MASTER CODE FUNCTIONS - FOR STEPS 1-3 PLEASE ENTER THE RELEVANT NUMBERS IN THE SEQUENCE SHOWN BELOW (EG. STEP1STEP2STEP3)								
							STEP 1 STEP 2 STEP 3	
CHANGE MASTER CODE	✓	✓	✓	✓	✓	✓	[logo*] [Current Master Code] OR [logo*] [Current Master Card] 01 [New Master Code] [New Master Code] OR [New Master Card]	MASTER CODE IS EIGHT DIGITS.
CHANGE USER CODE FOUR DIGIT			✓				[logo*] [Master Code OR Master Card] 02 [New User Code - (4 digit)] OR [New User Card]	USER CODE IS FOUR DIGITS
CHANGE USER CODE SIX DIGIT					✓		[logo*] [Master Code OR Master Card] 02 [New User Code - (6 digit)] OR [New User Card]	USER CODE IS SIX DIGITS
DELETE USER CODE	✓	✓	✓	✓	✓	✓	[Master Code OR Master Card] OR [logo] [Master Card] 03 [New Sub-Master Code] OR [New Sub-Master Card]	OPENS LOCK AND DELETES USER CODE
SET / CHANGE SUB-MASTER CODE	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 05 [New User Code - (6 digit)] OR [New User Card]	SUB-MASTER CODE IS SIX DIGITS
SET PUBLIC SINGLE USER MODE	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 06 [New User Code - (6 digit)] OR [New User Card]	USER CODE IS SIX DIGITS
SET PRIVATE SINGLE USER MODE	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 06 [New User Code - (6 digit)] OR [New User Card]	USER CODE IS FOUR DIGITS
DELETE SUB-MASTER CODE	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 07	DELETES SUB-MASTER CODE
OPEN LOCK	✓	✓	✓	✓	✓	✓	[Master Code OR Master Card] OR [logo] [Master Card]	DELETES USER CODE IN PUBLIC MODE
CLOSE LOCK	✓	✓	Auto	Auto	Auto	Auto		RE-LOCKS AUTOMATICALLY AFTER 4 SECONDS
SET PUBLIC MODE (FOUR DIGIT CODES)	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 08	DELETES ALL EXISTING USER CODES
SET PRIVATE MODE (FOUR DIGIT CODES)	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 09 [New User Code] OR [New User Card] OR [logo] [New User Card]	DELETES ALL EXISTING USER CODES
SET TECHNICIAN MODE	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 10 [New Technician Code]	TECHNICIAN CODE IS SIX DIGITS
REMOVE TECHNICIAN MODE	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 11	DELETES TECHNICIAN CODE
SET AUDIBLE BUTTONS ON	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 12	UNIT WILL BEEP ON EACH BUTTON PRESS
SET AUDIBLE BUTTONS OFF	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 13	UNIT WILL OPERATE SILENTLY
SET UNSUCCESSFUL CODE LOCKOUT ON	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 24	WILL LOCKOUT IF WRONG CODE ENTERED FOR 5 TIMES
SET UNSUCCESSFUL CODE LOCKOUT OFF	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 25	WILL NOT LOCKOUT IF WRONG CODE ENTERED FOR 5 TIMES
ENABLE AUTOMATIC BATTERY CHECK	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 33	ENABLE AUTOMATIC BATTERY CHECK
DISABLE AUTOMATIC BATTERY CHECK	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 34	DISABLE AUTOMATIC BATTERY CHECK
ALLOW USER CHANGE OWN CODE			✓	✓	✓		[logo*] [Master Code OR Master Card] 52	USER IS ALLOWED TO CHANGE THEIR CODE
DISALLOW USER CHANGE OWN CODE			✓	✓	✓		[logo*] [Master Code OR Master Card] 53	USER IS NOT ALLOWED TO CHANGE THEIR CODE
SET DOUBLE USER CODE ENTRY MODE	✓	✓					[logo*] [Master Code OR Master Card] 54	TO LOCK, USER CODE WILL BE ENTERED ONCE
SET SINGLE USER CODE ENTRY MODE	✓	✓					[logo*] [Master Code OR Master Card] 55	TO LOCK, USER CODE WILL BE ENTERED TWICE



NIMBUS 3963/3964 RFID Digital Combination Lock

FUNCTION	MODE						KEY SEQUENCE	NOTES
	Public	Private			RAS			
	4 digit (Single User)	6 digit (Single User)	4 digit (Single User)	4 digit (Multi User)	8 digit (Single User)	RAS Code		
MASTER CODE FUNCTIONS FOR STEPS 1-3 PLEASE ENTER THE RELEVANT NUMBERS IN THE SEQUENCE SHOWN BELOW (EG. STEP1STEP2STEP3)								
STEP 1 STEP 2 STEP 3								
HIGH SPEED DETECTION	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 67	HIGH BATTERY CONSUMPTION
NORMAL SPEED DETECTION	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 68	NORMAL BATTERY CONSUMPTION
SLOW SPEED DETECTION	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 69	LOW BATTERY CONSUMPTION
CHECK FIRMWARE VERSION	✓	✓	✓	✓	✓	✓	[logo*] [Master Code OR Master Card] 70	WILL REPLY BY LED : NO APP = RED LED, WITH APP = GREEN LED
SUB-MASTER CODE FUNCTIONS - FOR STEPS 1-3 PLEASE ENTER THE RELEVANT NUMBERS IN THE SEQUENCE SHOWN BELOW (EG. STEP1STEP2STEP3)								
CHANGE USER CODE			✓	✓	✓		[logo*] [Sub-Master Code OR Sub-Master Card] 02 [New User Code][New User Code] OR [New User Card]	USER CODE IS FOUR OR SIX DIGITS. (FOUR DEFAULT)
CHANGE SUB MASTER CODE	✓	✓	✓	✓	✓	✓	[logo*] [Current Sub-Master Code OR Current Sub-Master Card] 03 [New Sub-Master Code] OR [New Sub-Master Card]	SUB-MASTER CODE IS SIX DIGITS.
DELETE USER CODE	✓	✓					[Sub-Master Code OR Sub-Master Card] OR [logo] [Sub-Master Card]	OPENS LOCK AND DELETES USER CODE
OPEN LOCK	✓	✓	✓	✓	✓	✓	[Sub-Master Code OR Sub-Master Card] OR [logo] [Sub-Master Card]	DELETES USER CODE IN PUBLIC MODE
CLOSE LOCK	✓	✓	Auto	Auto	Auto	Auto		RE-LOCKS AUTOMATICALLY AFTER 4 SECONDS
ADD CHANGE USER ACCESS CODE							[logo*] [Sub-Master Code OR Sub-Master Card] 05 [Two digit User Number] [Four digit User Code]	
DELETE USER ACCESS CODE							[logo*] [Sub-Master Code OR Sub-Master Card] 06 [Two digit User Number]	
USER CODE FUNCTIONS - FOR STEPS 1-3 PLEASE ENTER THE RELEVANT NUMBERS IN THE SEQUENCE SHOWN BELOW (EG. STEP1STEP2STEP3)								
CHANGE USER CODE		✓					[logo*] [Current User Code OR Current User Card] 02 [New User Code] [New User Code] OR [New User Card]	USER CODE IS FOUR DIGITS.
OPEN LOCK	✓	✓					[User Code OR User Card] OR [logo] [User Card]	
CLOSE LOCK	✓	✓					[User Code OR User Card] OR [logo] [User Card]	WHEN SINGLE USER CODE ENTRY MODE IS SET
CLOSE LOCK	✓	✓					[User Code] [User Code] OR [UserCard] OR [logo] [User Card]	WHEN DOUBLE USER CODE ENTRY MODE IS SET
CLOSE LOCK			Auto	Auto	Auto		[User Code OR User Card] OR [logo] [User Card]	RE-LOCKS AUTOMATICALLY AFTER 4 SECONDS
CLOSE LOCK				Auto			[Two digit User Number] [Four digit User Code]	RE-LOCKS AUTOMATICALLY AFTER 4 SECONDS
CHANGE ACCESS CODE				✓			[logo*] [Access Code] 02 [New 4 digit User Code][New 4 digit User Code]	ACCESS CODE IS TWO DIGIT USER NUMBER + FOUR DIGIT USER CODE
TECHNICIAN CODE FUNCTIONS								
OPEN LOCK	✓	✓					[Technician Code OR Technician Card] OR [logo] [Technician Card]	DOES NOT DELETE USER CODE
CLOSE LOCK	✓	✓	Auto	Auto	Auto	Auto		RE-LOCKS AUTOMATICALLY AFTER 4 SECONDS
FUNCTIONS AVAILABLE TO ALL CODES								
BATTERY CHECK	✓	✓	✓	✓	✓	✓	[logo*] [logo] OR [logo*] [logo*]	REPLACE BATTERIES IF RED LIGHT SHOWS



NIMBUS 3963/3964 RFID - Remote Allocation System (RAS)

FUNCTION	MODE						KEY SEQUENCE	NOTES		
	Public	Private	RAS	4 digit (Single User)	6 digit (Single User)	4 digit (Single User)				
MASTER CODE FUNCTIONS - FOR STEPS 1-3 PLEASE ENTER THE RELEVANT NUMBERS IN THE SEQUENCE SHOWN BELOW (EG. STEP1STEP2STEP3)										
							STEP 1	STEP 2	STEP 3	
SET/RESET RAS MODE	✓	✓	✓	✓	✓	✓	[logo*] [Old Master Code OR Old Master Card]	20	[New Serial Number]	SERIAL NUMBER IS DEFINED HERE FOR EACH LOCK
SET/RESET RAS ONE TIME USE MODE	✓	✓	✓	✓	✓	✓	[logo*] [Old Master Code OR Old Master Card]	22	[New Serial Number]	SERIAL NUMBER IS DEFINED HERE FOR EACH LOCK
SET/RESET RAS TWO TIME USE MODE	✓	✓	✓	✓	✓	✓	[logo*] [Old Master Code OR Old Master Card]	32	[New Serial Number]	SERIAL NUMBER IS DEFINED HERE FOR EACH LOCK
CHANGE RAS CODE TO FRIENDLY CODE						✓	[logo*] [Ras Code]	04	[New User Code] [New User Code]	RAS CODE STILL WORKS AS WELL AS THE NEW FRIENDLY CODE
DELETE RAS FRIENDLY CODE OR CARD						✓	[logo*] [Ras Code OR New User Code]	05		NEW USER CODE OR USER CARD WILL BE DELETED
EXIT RAS MODE INTO PUBLIC MODE	✓	✓	✓	✓	✓	✓	[logo*] [Old Master Code OR Old Master Card]	08		DELETES ALL EXISTING USER CODES
EXIT RAS MODE INTO PRIVATE MODE	✓	✓	✓	✓	✓	✓	[logo*] [Old Master Code OR Old Master Card]	09	[New User Code] OR [New User Card]	DELETES ALL EXISTING USER CODES
CHANGE MASTER CODE	✓	✓	✓	✓	✓	✓	[logo*] [Old Master Code OR Old Master Card]	01	[New Master Code] [New Master Code] OR [New Master Card]	MASTER CODE IS EIGHT DIGITS
OPEN LOCK	✓	✓	✓	✓	✓	✓	[User Code]			
OPEN LOCK	✓	✓	✓	✓	✓	✓	[Old Master Code OR Old Master Card] OR [logo][Old Master Card]			WHEN SINGLE USER CODE ENTRY MODE IS SET
CLOSE LOCK	✓	✓	AUTO	AUTO	AUTO	AUTO				WHEN DOUBLE USER CODE ENTRY MODE IS SET
SET AUDIBLE BUTTONS ON	✓	✓	✓	✓	✓	✓	[logo*] [Old Master Code OR Old Master Card]	12		UNIT WILL BEEP ON EACH BUTTON PRESS
SET AUDIBLE BUTTONS OFF	✓	✓	✓	✓	✓	✓	[logo*] [Old Master Code OR Old Master Card]	13		UNIT WILL OPERATE SILENTLY
BATTERY CHECK	✓	✓	✓	✓	✓	✓	[logo*] [logo] OR [logo*][logo*]			REPLACE BATTERIES IF RED LIGHT SHOWS

NOTES
ALL ACCEPTABLE BUTTON PRESSES ARE SIGNIFIED BY A GREEN OR ORANGE LIGHT.
INCOMPLETE FUNCTIONS "TIME-OUT" AFTER 4 SECONDS.
ERRORS AND "TIME-OUTS" ARE SIGNIFIED BY FLASHING RED LIGHT.
FOLLOWING AN ERROR OR "TIME-OUT", UNIT REVERTS TO PREVIOUS SETTINGS.
IN PUBLIC MODE, FUNCTIONS WORK ONLY IF THE LOCK IS UNLOCKED.

BATTERY CONDITION INDICATOR
GREEN LIGHTS - EXCELLENT
ORANGE LIGHTS - GOOD
RED LIGHTS - LOW
FLASHING RED LIGHTS - VERY LOW
RED LIGHT - CHANGE BATTERIES AS SOON AS POSSIBLE
FLASHING RED LIGHT PRIOR TO LOCK OR UNLOCK INDICATES LOW BATTERY VOLTAGE
CHANGE BATTERIES AS SOON AS POSSIBLE

* PRESS AND HOLD LOGO BUTTON FOR 2 SECONDS

MASTER CODE (8 digits)	SUB-MASTER CODE (6 digits) (No Default)	USER CODE (4 OR 6 DIGITS)
□□□□□□□□	□□□□□□	□□□□
ENSURE THAT YOU CHANGE THE DEFAULT MASTER CODE TO YOUR OWN MASTER CODE AND KEEP A SAFE RECORD - IT IS NOT POSSIBLE TO PROGRAM THE LOCK WITHOUT IT		

LOWE & FLETCHER LTD

Moorcroft Drive, Wednesbury, West Midlands, WS10 7DE, UK
 Tel: +44 (0) 121 505 0400 Fax: +44 (0) 121 505 0420
 Email: sales@lowe-and-fletcher.co.uk
 www.lowe-and-fletcher.co.uk

LOWE & FLETCHER, INC.

650 Airport Place, Norton Shores, MI-49441, Michigan, USA
 Tel: +1 (616) 994 0490 Fax: +1 (616) 994 0480
 Email: sales@loweandfletcherinc.com
 www.loweandfletcherinc.com

EURO-LOCKS SA NV

Rue de la Fontaine 8, 6600 Bastogne, Belgium
 Tel: +32 61 212 261 Fax: +32 61 212 265
 Email: sales@euro-locks.be
 www.euro-locks.be

EURO-LOCKS SA

1 Rue du Stade, 57730 Folschviller, France
 Tel: +33 (0) 3 87 92 61 11 Fax: +33 (0) 3 87 92 42 04
 Email: euro-locks@euro-locks.fr
 www.euro-locks.fr

EURO-LOCKS GMBH

Am Bruchwald 22, 66280 Sulzbach/Neuweiler, Germany
 Tel: +49 (0) 6897 9072 0 Fax: +49 (0) 6897 9072 99
 Email: vertrieb@euro-locks.de
 www.euro-locks.de

EURO-LOCKS SP. Z O.O.

ul. Pawła 29, 41-708 Ruda Śląska, Poland
 Tel: +48 (32) 344-78-70, -82, -84 Fax: +48 (32) 344-78-74
 Email: sekretariat@euro-locks.pl
 www.euro-locks.pl